Maintenance schedule

0317 - R 1200 GS

00 00 128 BMW Inspection (see Maintenance Schedule) (every 20,000 km)

Equipment trim-level variant:

0771 - Cross-spoked wheels 0645 - (BMW Motorrad Integral ABS)

Reading fault memory with (BMW Motorrad) diagnostic system	
Performing bleed test with the BMW Motorrad diagnostic system	
Engine-oil change, with filter	
23 00 510 Gearbox-oil change (maintenance) *)	every two years or every 40,000 km
Adjusting valve clearance	
12 12 509 Replace all spark plugs (as part of maintenance) *)	every 40,000 km
Replacing air filter element	
12 31 657 Repleace belt for generator (as part of maintenance) *)	every 60,000 km
Visual inspection of hydraulic clutch system	
Checking front brake discs for wear	
Checking front brake pads for wear	
Checking brake-fluid level, front brakes	
Checking rear brake disc for wear	
Checking rear brake pads for wear	
Checking brake-fluid level, rear brakes	
Checking freedom of movement of throttle cable and checking for kinks a	nd chafing
Checking tyre pressures and tread depth	
Checking spoke tension, adjusting if necessary	
Checking ease of movement of side stand	
Checking ease of movement of centre stand	
Checking lights and signalling equipment	
Function test, engine start suppression	
Checking synchronisation	

*) Billed as a separate item	not as per the normal schedule	
Confirming BMW Service in on-board d	ocumentation	
Checking battery charge state		
Reading fault memory with (BMW Moto	rrad) diagnostic system	
Test ride as final inspection and functio	n check	